





# Speece cones saturate water with oxygen, ozone

1 March 2009 By Gary Rogers, Ph.D., P.E.

Easy to install and operate, they are virtually maintenancefree



Speece cone systems offer highly efficient diffusion of oxygen into water to raise oxygen content.

Speece cones offer a very efficient method for increasing oxygen levels in water for aquaculture applications as well as zoo and aquarium exhibits. The oxygen cone concept was originally developed by Dr. Richard Speece at Vanderbilt University in Nashville, Tenn., USA. Speece initially called his system a down-flow bubble contact aeration apparatus, a device used to supersaturate water with oxygen.

The complete system included an inverted funnel open at the bottom with a water pump at the top, a bubble diffuser located about middepth and a source of oxygen gas. The design has since been modified to an enclosed cone-shaped chamber.

The early design of the cone was limited to the wildlife hydrostatic pressure as defined by the depth at which the funnel was placed in the water body. The newer enclosed cones can be used at higher pressures limited by the type of material used for construction. Cones have been designed using polyvinyl chloride, fiberglass or stainless steel materials.

### Gas transfer

The transfer of oxygen gas to the water follows Henry's Law, which is used to determine saturation concentrations of dissolved gases. According to Henry's Law, under steady-state conditions, the partial pressures of dissolved gases in water are in balance with the pressures of the same gases in the atmosphere above the water.

When the pressure of the gases over water is decreased, the amount of dissolved gas also decreases. In addition, the saturation concentrations of those gases will vary depending on temperature, salinity and pressure. Higher pressure increases the amount of gas dissolved per unit volume, so the saturation concentration for a gas is higher at higher pressure or in deeper water. The inverse is the case for temperature and salinity. Water at higher temperature or salinity dissolves less gas per unit volume.



Oxygen cones are fairly easy to install and operate, and require no maintenance.

# **Cone operation**

Speece oxygen cones are fairly easy to install and operate. Once installed, they are virtually maintenance-free. Water enters at the top of the cone and flows downward. At the same time, oxygen is introduced through a fitting at or near the top of the cone. The downward-flowing water counteracts the buoyancy of the rising oxygen bubbles. The bubbles are kept in suspension, no matter how large or small they are. Because the cone is pressurized, effluent water becomes supersaturated with oxygen by the time it reaches the tank.

The design of the cone optimizes oxygen transfer, and efficiencies up to 100 percent are possible. Concentrations of oxygen greater than saturation can be obtained depending on various operational parameters. For example, Speece cones can provide dissolved oxygen levels of 25-50 mg/l depending on flow rate, cone size, temperature and pressure.

Although cones can be designed to handle full flow in a recirculating system, they are more often plumbed in a side stream configuration by pumping out of a sump. A side stream setup minimizes flow requirements while still providing very high levels of dissolved oxygen or ozone.

## **Additional components**

In addition to the cone, a few other items are necessary for operation. These include:

- Pipe side flange fittings. Outlet holes for mounting pipe flange fittings are custom. Flanges can be either American or European standard sizes.
- Bleed valve. The bleed valve purges gas trapped inside the cone during the start-up procedure.
- Outlet valve. An outlet valve regulates the operating pressure within the cone.
- Pressure gauge. The pressure gauge monitors the pressure within the cone.

In some cases, a venturi is used to introduce oxygen, although it is not necessary. The venturi injection method has the added benefit of improved oxygen dissolution in the water due to the turbulence created in the venturi. In addition, a venturi provides other advantages, including control of full flow line pressure, lower

energy requirements for pumping and a limited space requirement.

## **Ozone applications**

Speece cones are also very efficient at dissolving ozone in water for aquaculture or other uses. Oxygen cone ozonation eliminates the need for venting gas or an ozone destruct unit, as efficiencies are near 100 percent. In addition, the economics of ozonation can be greatly improved in terms of lower capital, maintenance and operational costs.

### **Precautions**

Two safety considerations are important when working with oxygen cones. First, fiberglass cones are not designed to operate at pressure greater than 21 psi. Failure to keep the operating pressure at or below this level can result in permanent damage to the cone and/or serious injury to the operator.

Secondly, highly concentrated sources of oxygen can be fire or explosion hazards. Pure oxygen at high pressure in combination with a spark can lead to an explosion. Therefore, the design and manufacture of oxygen systems requires that potential ignition sources are eliminated.

(Editor's Note: This article was originally published in the March/April 2009 print edition of the Global Aquaculture Advocate.)

# **Author**



GARY ROGERS, PH.D., P.E.

Aquatic Eco-Systems, Inc. 2395 Apopka Boulevard Apopka, Florida 32703 USA

garyr@aquaticeco.com (mailto:garyr@aquaticeco.com)

Copyright © 2023 Global Seafood Alliance

All rights reserved.